

NZ 42/25 NEW ZEALAND - South Island - East Coast - Akaroa Harbour - French Bay. Aids to Navigation

1. Chart NZ 6324 [071/24]

Insert		43°48'.38S., 172°57'.37E.
	R	
		43°48'.37S., 172°57'.54E.
	G	

2. Chart NZ 6324 (plan, French Bay) [071/24]

Insert		43°48'.38S., 172°57'.37E.
	R	
		43°48'.37S., 172°57'.54E.
	G	
		43°48'.35S., 172°57'.56E.
	R	
		43°48'.45S., 172°57'.67E.
	G	
		43°48'.42S., 172° 57'.68E.
	R	