


NZ 67/26

NEW ZEALAND - South Island - North Coast – Tasman Bay / Te Tai-o-Aorere and Port Taranaki. Aids to Navigation

1. Chart NZ 6144 [020/26]


Amend




, to,




41°02'.99S., 173°01'.35E.




, to,




41°01'.14S., 173°01'.33E.




, to,




40°58'.93S., 173°03'.00E.




, to,



40°56'.56S., 173°03'.65E.



, to,



40°54'.94S., 173°03'.88E.

light to, Fl.R.5s6m7M

40°49'.21S., 172°53'.41E.

light to, Fl.G.5s6m7M

40°49'.30S., 172°53'.39E.

2. Chart NZ 6144 (plan, Port Taranaki) [020/26]

Amend

light to, Fl.G.5s6m7M

40°49'.265S., 172°53'.521E.

Replace

★ Fl.R.5s6m3M , with, ★ Fl.R.5s6m7M

40°49'.227S., 172°53'.639E.

NZ Light List: 4199, 4199.1

Tasman District Council
HITS 6144/92, HITS 6144/93